I'm not robot

Hard reset foscam fi8910w

Foscam reset camera.

This is the user manual for a product called Foscam Intelligent Technology Co., Ltd. The document appears to be divided into sections, starting with key features and read before use instructions. The contents page lists various topics such as device status, alias settings, date and time settings, and basic network settings. UPnP Settings and Configuration Options ========== This section outlines various settings for Foscam cameras, including: * DDNS Service Settings (page 3) * Mail Service Settings (page 4) * FTP Service Settings (page 5) Default alias setting is Anonymous, allowing users to define a name for their camera. Time zone selection is also available, with options to sync with NTP Server or PCTime. Device name modification is possible by entering a preferred name and selecting it as the device name. This allows users to identify multiple cameras. Selecting the time zone belonging to your region is crucial for accurate timekeeping. For more information, refer to page 5. Scan the QR code on page 5 to download the Foscam app or check it out in the app stores. If you need to reset your camera's settings to their factory defaults, follow these steps: 1. Locate the reset button and press it for approximately 30 seconds (or 10-15 seconds for some models). 2. The camera will reboot itself, restoring its factory settings. 3. After the reset, log in with username "admin" and a blank password. 4. You'll be prompted to enter a new username and password after your first login. The reset button is located on: 1. Indoor PT cameras: either at the bottom of the camera or on the side of the body (accessible using a paperclip). 2. Other models: consult your device's documentation for specific location information. Modified on: Tue, Jan 15, 2019 at 3:19 PM Applies to: All Foscam cameras The location of the Reset button varies among different camera models. Generally, it is found on the back or tail cable of indoor and outdoor dome, bullet, PTZ, and Fosbaby series cameras. For specific models: - Indoor Dome cameras: The Reset button is located on the tail cable coming out of the back of the camera. - Outdoor Bullet style cameras: The Reset button is also located on the tail cable coming out of the back of the camera. - Outdoor PT cameras: Similar to other outdoor models, the Reset button is found on the tail cable coming out of the back of the camera. - Fosbaby series cameras: In this case, the Reset button is situated on the body of the camera. If after pressing the reset button for 30 seconds, the camera still does not successfully reset, try powering cycling it off and on again. Repeat the process until successful reset. If issues persist, contact our Technical Support department at 1-844-344-1113 (US) for further assistance.